AERODROME GROUND TWR - 118.100 /118.500 ATIS - 124.150 /121.950 APRON ELEV LISBOA / LPPT CLD - 118.950 /118.500 GND - 121.750 /118.500 MOVEMENT CHART - ICAO 114 m TAXI ROUTE PROCEDURES ARRIVAL / DEPARTURE RWY03 HOTSPOT ARRIVAL RWY03
- Pilots should plan their landing to vacate RWY03 via TWY "HN", in order to minimize runway occupancy time, except by agreement of ATC. TAXIWAY CAUTION! - If, for any particular reason, you wish to vacate via taxiway "S1" or RWY17, make the request on first contact with TWR. RUNWAY DO NOT CROSS/ENTER RWY 03/21 WITHOUT ATC CLEARANCE. RWY 03-21 - 3705 x 45m Asphalt "42" "50" RWY 17/35-2315 x 45m Asphalt "70" IN ORDER TO AVOID JET BLAST HAZARDS, IF NOT CLEARED TO CROSS/ENTER RWY17/35, AIRCRAFT SHALL STOP AND HOLD PARALLEL WITH RWY 17/35 BEFORE TWY "G1","Y","M1" OR "K". MILITARY APRON "80 " CAUTION!
DO NOT CROSS/ENTER RWY 17/35
WITHOUT ATC CLEARANCE. AFTER TWY "U4" CAUTION, RWY 17/35 IS AHEAD!

New Javout Taxiways Mar

© NAV Portugal, E.P.E. AIRAC 002-17