



In case of RCF:

Squawk 7600. Climb FL070 straight-ahead to intercept and proceed R095 LIS DVOR/DME. At 24 DME LIS DVOR/DME turn right to intercept and proceed R189 FTM DVOR/DME. When crossing R071 ESP DVOR/DME turn right to intercept and proceed R074 ESP DVOR/DME to ADSAD holding. After completing one holding pattern proceed on track 297° to intercept and proceed on RDL146 CAS DVOR/DME to PT541 descending to 3000ft to perform another ILS approach.

Pagination changed.